

REMARK: FORM A SLOPE SO THAT PE-CONNECTION WILL BECOME THE LAST TO STRIP OFF IN CASE OF PULLING FORCE TO MAINS CABLE:

KEEP POWER WIRES AWAY FROM SIGNAL LINES. DRILL AC WIRES FIRMLY AND GIVE THEM SEPARATE WAY, PUT FILAMENT'S POWER WIRES WELL DRILLED ALONG THE INNER CHASSIS BEND AWAY FROM THE REST.

SIGNAL WIRES FROM INPUT SOCKETS TO V1 AND FROM V1 TO VOLUME POT SHOULD BE SHIELDED. ALWAYS KEEP WIRES AS SHORT AS POSSIBLE.

Princeton Reverb Amp Clone (AA1146)						
Sheet Layout						
Code BB2020	Document princeton_reverb_docs_V2.spi8				Rev. A6	
Date 10.02.2025		Last edit	13:56:38	Sheet	3 of 4	